

## Features of the M8004

**C.** The red indicator light flashes when the telephone rings and when you have a voice message (if you subscribe to a voice messaging service with voltage message waiting).

**D.** Use **Flash** to access telephone network services such as Call Waiting and Three-Way Calling. (To subscribe to these services, contact your telephone company.)

**Answering a Call Waiting call** – When you hear the Call Waiting tone, press **Flash** to place your original call on hold and answer the new call. To return to the original call, press **Flash** again. Press **Flash** to alternate between calls.

**Making a Three-Way call** – First, make a call. When the first call is answered, press **Flash**. That call is put on hold, and you will hear a dial tone. Make the second call. When the second call is answered, press **Flash** again to link the calls together.

**E.** Press **Redial** to redial the last telephone number that was dialed.

**F.** Press and hold down **Mute** when you don't want your caller to hear you. Release **Mute** when you want to be heard.

**G.** Ringer Volume – Slide this switch to set the loudness of the ringer.

**H.** Handset Speaker Volume – Slide this switch to set the loudness of the handset.

